

AF-100-3P

 **BLACK & DECKER**®



1


In order to replace or rewind the spool or clear a jam:

1. Disconnect the power source.
2. Release tabs as shown in (fig. 1) to remove the cover & spring.
3. Clear any broken line or debris and replace or rewind spool.
4. Insert the line end through the eyelet in the spool hub as shown in (fig. 2). Maintain tension by pulling the line through the hole while placing the spool into the hub (arrow side up). See (fig. 3).
5. Press the spool down and rotate it until it drops into place. (When in place, the spool will turn a few degrees left and right freely.)
6. Snap hub cover & spring in place. Connect power source and turn the tool on. You will hear the nylon line being cut automatically to the proper length.



2

CAUTION: Always wear eye protection. Unplug tool before changing, installing, or removing accessories. Read tool instruction manual for additional safety precautions before using this accessory.



3



www.BlackandDecker.com

1-800-544-6986

